

Schneider Electric Industries SAS
 35, rue Joseph Monier
 92500 Rueil-Malmaison, France
www.schneider-electric.com

This product must be installed, connected and used in compliance with applicable standards and/or installation regulations. As standards, specifications and designs develop from time to time, always ask for confirmation of the information given in this publication.


Ce produit doit être installé, connecté et utilisé conformément aux normes applicables et/ou règles d'installation. Du fait que les normes, les spécifications et les sché-

mas peuvent être modifiés, nous vous recommandons de vérifier que la documentation de cette publication soit mise à jour.

Este producto debe ser instalado, conectado y utilizado en acuerdo con las normas aplicables y/o las reglas de instalación. Dado que las normas, las especificaciones y los diseños se desarrollan de vez en cuando, se recomienda se aseguren que la información dada en esta publicación sea la correcta.

Actassi 19-C

BBV12975-04




(x1)


(x2)

(x24) ?

VDIG118241U50	Cat. 5e UTP	
VDIG118241F50	Cat. 5e STP	
VDIG118241U60	Cat. 6 UTP	
VDIG118241B60	Cat. 6 STP	
VDIG118241BX0	Cat. 6 _A STP	
VDIG112241U	UTP	
VDIG112241F	STP	

 **VDIM11U24X**  (x24)

 **VDIM48E011**   (x10)





(x1)

(x2)

(x24) ?

VDIG018241U50	Cat. 5e UTP	
VDIG018241F50	Cat. 5e STP	
VDIG018241U60	Cat. 6 UTP	
VDIG018241B60	Cat. 6 STP	
VDIG018241BX0	Cat. 6 _A STP	
VDIG012241U	UTP	
VDIG012241F	STP	

 **VDIM11U001**  (x1) (x4)

 **VDIM11U002**  (x4)

January 2012

